

























# Assembly Instructions for 145973




			
A   2	B   2	C   1	D   1
			
E   2	F   1	H   2	I   2
			
J   1	K   2	L   2	M   1
			
N   1	Q   6	S   4	T   8
			
U   12   4	W   12   4	Y   2	Z   12   4
			
AA   2	BB   1		


1




2




3




4




5




6




7




8



9



10



11

